

# ToolsOnAir-Support

[Portal](#) > [Knowledgebase](#) > [Knowledgebase just:in](#) > [General](#) > [How to use the reference input on AJA boards as timecode input](#)

## How to use the reference input on AJA boards as timecode input

Chris - 2018-05-25 - in [General](#)

Some AJA cards allow to turn the Reference Input into a TC Input.

So if you want to use the Reference input on some AJA boards as timecode input in just:in, please follow this guide:

- Open the AJA Control Panel and switch to the Timecode tab
- Then select LTC Port as Input option



- Then open the just:in engine application and make sure that the option "Use External LTC timecode" is disabled. This screenshot can look slightly different, depending on the version you are using.



- Open the interface application and connect to the channel
- Select "Capture Card LTC" as timecode source

- You should see the correct timecode now in the user interface.

If this is not working, please let us know.